

## DIRECTIONS FOR ASSEMBLY OF BOAT HOOK TO POLE

Use center punch to mark on hook: north, south, east and west (make sure each mark is at least 5/8" up from bottom of pennant hook). Place hook securely on 1-1/2" OD structural aluminum pipe. Drill north hole through boat hook and pole with a 1/4" drill bit. Place 1/4" drive rivet through pole and hook and hit 1/4" drive rivet squarely with hammer to attach hook to pole. Fasten boat hook to pole in four places, starting at north position and proceed to south, east and west marks. Place plastic red end cap on opposite end of pole

Contents: 1 - boat hook  
4 - 1/4" drive rivets  
1 - red end cap

Elisha Webb and Son Co. , Inc ~ Phila., PA  
215-535-2628

